



Mounting Instructions
- CUT OUT 3.34" x 1.5"
(85mm x 38.1mm) and
add 4- 5/32" (4mm) thru
holes as measured
- Drop 1330-FTM-PM
into place bringing the
studs through the 5/32"
(4mm) holes and tighten
down with supplied nuts.